

Full Encapsulation Screw Preparation Instructions

Our standard coating thickness options for Full Encapsulation are as follows:

- .003"/.004" per side for Chrome Replacement
- .005" per side or .010" overall
- .010" per side or .020" overall.

Undercut Option #1
Start undercut at the bearing.



Undercut Option #2
Start undercut after the pocket.

New screws only: The root should be undercut .004" overall more than the O.D. undercut.
Example: If the O.D. is undercut .010" per side, undercut the root .012" per side.



Undercut the register the same amount as the O.D.

